

AcuPoint Analysis

FOREARM NUMBNESS

(DESCRIPTIONS)

- H03** At the extreme end of the inner crease of the elbow. Bend the arm tightly and place the Acu-Ki at the extreme inner edge of the elbow crease formed. Relax your arm and begin the stimulation.
- LU09** On the crease closest to the hand of the inner wrist, in line with the thumb.
- P06** The width of two thumbs (2 Cun) above the most prominent crease on the inner wrist, in line with the middle finger.
- P08** Between the second and the third metacarpal bones of the hand, where the tip of the middle finger touches when the fist is clenched.

