








AcuPoint Analysis INFECTI*ON*



- LI04** On the back of the hand between the thumb and index finger metacarpal bones. Find the spot midway on the bone that connects the index finger to the wrist. Sometimes this point is easy to find by squeezing two fingers together to form a small mound and marking an imaginary point at the peak of that mound. Then probe inward toward the main body of the hand, right on the bone.
- LI08** 4 Cun below LI11 (On the extreme end of the outer crease at the elbow) on a line connecting LI05 and the end of the visible elbow crease or LI11.
- LI11** On the extreme end of the outer crease of the elbow. Bend your arm tightly and place your Acu-Ki on the end of the crease. Keep your massager in place while opening the arm and stimulate the point on your relaxed arm downward toward your forearm.
- LI13** On the front edge of the humerus (bone on your upper arm), 3 Cun above the elbow crease.
- SP10** The width of two thumbs above the top of the kneecap, in the inner thigh, approximately in line with the crown of the inner ankle.
- ST36** The width of one hand (3 Cun) below the bottom of the kneecap, and the width of one thumb (1 Cun) toward the outside of the leg (direction of the small toe.) Found in the trough or valley where the two most prominent bones of the calf come together.
- UB17** 1.5 Cun from the spine midline, along an imaginary line drawn between the bottoms of the shoulder blades (scapula). Easily stimulated with the Back-eze.